Operation Manual   LF

WIRING & FUNCTIONS (AK)

Different applications require different functions. It is highly recommended to determine and configure the required functions prior to Installation; (refer to 'CONTROL WIRES' section).

LIGHTBAR WIRING

RED —— to +VDC *with Fuse*.

BLACK—— to chassis ground

WHITE —— to +VDC to activate ALL MODULES - R65 Double flash (except ICS modules).

YELLOW—— to +VDC to activate ICS modules.