

# DIAMONDBACK MAGNETIC MOUNT



Model: with Dual button cigar-plug.



**WARNING:**

It is not recommended to use magnetically mounted warning devices on vehicles in motion. Usage is at the sole risk and responsibility of the user.



## FLASH PATTERNS

Momentarily push Flash Pattern button.

- Once for next pattern
- Quickly 3 times for reset to FP#1

FP#	Flash Patterns	FP#	Flash Patterns	FP#	Flash Patterns
1	Random	9	Single H/L (split)	17	Single H/L (all)
2	Single (split)	10	Single (all)	18	Steady (half)
3	Double (split)	11	Double (all)	19	Steady (all)
4	Quad (split)	12	Quad (all)	20	Single (2Hz)
5	Quint (split)	13	Quint (all)	21	Double (2Hz)
6	Mega (split)	14	Mega (all)	22	Triple (2Hz)
7	Ultra (split)	15	Ultra (all)	23	Quad (2Hz)
8	Single-Quad (split)	16	Single-Quad (all)		

**Note:** This unit may not be factory set at FP#1

## MAGNET MOUNT

