
LIGHTHEAD Manual



To Chassis Ground......BLACK

For Simultaneus or Alternating Flash......WHITE

Group1 Heads: (Wiring-WHITE connected to RED) will flash together Group2 Heads: (Wiring-WHITE not connected to RED) will flash together

Group1 Heads will alternate with Group2 Heads

For Synchronization & Flash Patterns.....YELLOW

Connect YELLOW wires of all heads together for synchronization *All heads must be set at the same pattern

Momentarily apply + VDC to **YELLOW** wire:

- · once for next pattern
- · quickly three times for reset

Note: This unit may not be factory set at pattern 1.

FP#	Flash Patterns		
1	Random	7	Quad
2	Steady	8	Quint
3	Single	9	8 Flash
4	Mega	10	Single-Quad
5	Double	11	Single H/L
6	Triple	12	Single-Triple-Quint