# *LED Beacon Manual*

Use an electrical conducting item and momentarily contact both pins:

· Once for next pattern
· Quickly 3 times for reset to FP#0

FP#	FLASH PATTERNS
0	Ultra (default)
1	Double
2	Triple
3	Quad
4	Quint
5	Single
6	Mega
7	Single-Triple-Quint
8	Single H/L