

LED FLUSH MOUNT KIT USER MANUAL

12-24VDC

CONTENTS



LIGHTHEAD x 2pcs



MOUNTING GROMMET x 2pcs




EXTENSION CABLE



LED CONTROLLER

WIRING & FUNCTIONS



NOTE: Each warning mode may be set to different Flash Pattern & Colour Mode.

OPERATION

For Synchronization:

Connect **YELLOW** wires of all lightheads together for synchronization.
(All the lightheads should be set to the same Flash Pattern)

For Warning Colour Mode:

Each Warning Mode (**RED**, **WHITE** or **RED+WHITE**) may be set to warning in **COLOUR 1**, **COLOUR 2** or **COLOUR 1 2**. To change Warning Colour Mode:

- Choose the desired warning mode to change and apply +VDC to its activation wire (**RED**, **WHITE** or **RED+WHITE**) with **YELLOW** wire simultaneously to enter *Setting Mode*; lighthead will display short flashes in its current Colour Mode.
 - Colour 1 (Warning Mode 1 Pre-set)
 - Colour 2 (Warning Mode 2 Pre-set)
 - Colour 1 alt. 2 (Warning Mode 3 Pre-set)
- Remove **YELLOW** wire from +VDC and momentarily apply to +VDC again to change Colour Mode.
- Once in desired Colour Mode, save and Exit *Setting Mode* by powering off the lighthead.

For Flash Pattern:

While a warning mode is activated, momentarily apply +VDC to **YELLOW** wire:

- once for next pattern
- quick three times to reset to FP#1 (see flash pattern chart)

Flash Pattern


1	Double [2Hz]	15	Random
2	Single [2Hz]	16	Double [2Hz] (SPLIT)
3	Triple [2Hz]	17	Single [2Hz] (SPLIT)
4	Quad [2Hz]	18	Triple [2Hz] (SPLIT)
5	Single	19	Quad [2Hz] (SPLIT)
6	Double	20	Single (SPLIT)
7	Quad	21	Double (SPLIT)
8	Quint	22	Quad (SPLIT)
9	Mega	23	Quint (SPLIT)
10	Ultra	24	Mega (SPLIT)
11	Single-Quad	25	Ultra (SPLIT)
12	Single H/L	26	Single-Quad (SPLIT)
13	Steady EF *	27	Single H/L (SPLIT)
14	Steady Scene		

* For use with external flasher controller.


INSTALLATION - FLUSH MOUNT

- Select a mounting location and drill one 1" (25.4mm) cut-out.


NOTE: Mounting surface thickness @ 0.8~2.0mm



- Ensure that triangle mark on the lens is aligned vertically.



- From the front, install MOUNTING GROMMET onto the cut-out, and then insert the LIGHTHEAD.



- Where necessary, apply silicone around the reverse side to prevent from rotating.

