
WORK LAMP Manual

OPERATION

RED wire: To +VDC

BLACK wire: To Chassis Ground (-)

INSTALLATION



00929

WORK LAMP Manual

OPERATION

RED wire: To +VDC

BLACK wire: To Chassis Ground (-)

INSTALLATION

