

4-LED LIGHTHEAD

12-24 VDC

WIRING

RED: To +VDC (fuse @ 3A)

BLACK: To Chassis Ground

WHITE: For steady burn, apply +VDC

YELLOW: For Synchronization:

Connect **YELLOW** wires of all heads together for synchronization
(all heads must be set at the same pattern)

For Simultaneous or Alternating Flash:

1. Apply +VDC to **RED** and **YELLOW** wires simultaneously to enter Grouping; lighthead will display short (single or double) flashes:
 - Single flash = Group1 • Double flash = Group2
2. Momentarily apply +VDC to **YELLOW** wire to change Groups:
 - Heads in the same Group flash together.
 - Group1 Heads alternate with Group2 Heads.

For Flash Patterns:

- Momentarily apply +VDC to **YELLOW** wire:
- once for next pattern
 - quickly three times for pattern 0

FLASH PATTERN

- | | | | |
|---|---------------------|----|-------------------|
| 0 | Random | 10 | Double (all) |
| 1 | Single (split) | 11 | Quad (all) |
| 2 | Double (split) | 12 | Quint (all) |
| 3 | Quad (split) | 13 | Mega (all) |
| 4 | Quint (split) | 14 | Ultra (all) |
| 5 | Mega (split) | 15 | Single-Quad (all) |
| 6 | Ultra (split) | 16 | Single H/L (all) |
| 7 | Single-Quad (split) | 17 | Steady (ca) |
| 8 | Single H/L (split) | 18 | Steady 4 (all) |
| 9 | Single (all) | | |

Note: This unit is not factory set at pattern 0

